## ZINC BOLLARD


#### Product Installation guide







MAKE SURE THE POWER IS OFF DURING INSTALLATION








### RISK OF FIRE AND ELECTRICAL SHOCK









- 2. The feeding voltage must not exceed the specified fixture voltage.
- 3. This product must be installed by an eligible electrician.
- 4. Make sure the luminaire is mounted to a secure structure. Failure to mount the fixture correctly could result in serious injury.
- 5. Class 1 must be earthed in a reliable way.









8. It is very important not to install a damaged product! This luminaire is properly packed to avoid being damaged during transit. Check for impaired objects before installation. Any damaged or broken item during or after assembly must be replaced.


Dimensions in inch.
















# ZINC BOLLARD

### Product Installation guide





- 1- Connect the luminaire to the mains cable using a waterproof connector
- 2- Remove the screwdriver and slide the pole downwards.



Fasten the luminaire using the provided screws.




## ZINC BOLLARD

#### **Product Installation guide**


Surface Bracket



Screw the bracket onto the offir reference. Make sure the main electrical cable is in between the brackets.



Connect luminaire to main cable using a waterproof connector



Fasten the luminaire using the provided screws.

Wiring

Non dimmable fixtures are attached to a 3 pole cable. The wiring to the main voltage should follow the color code below:

Line : Brown Neutral : Blue

Ground: Yellow/ Green

Dimmable fixtures (DALI or 1-10V) are attached to a 5 pole cable. The wiring to the main voltage should follow the below color code:

Line : Brown Neutral : Blue

Ground: Yellow/ Green

DIM+ : Gray DIM- : Black

